

Lichtlauf

Casino Floor
en

product description

Design Christoph Matthias, Gerd Pfarrè 2013

Twelve pentagons create a dodecahedron. Manufactured from light poly-carbonate, the dodecahedron becomes a lamp. The illuminant fills the room with a mild, constant light – no matter, if it is a single lamp or a group. It can be set everywhere around a socket outlet.

Light source: per light 1 x max. 70W, E27

Available in three sizes:

S: approx. Ø 37cm, M: approx. Ø 44cm, and L: approx. Ø 55cm

enclosed

Casino

technical data

230V ~ 50Hz
1x max. 70W, E27



Type:
indoor light IP20

suitable illuminants energy class: E - A++
are available

safety note

Follow always the hints of this instruction for a safe assembly and use of these lights. Keep the assembly instruction for further questions.

The assembly and the electric supply must be done by an electric professional. Local installation regulations have to be respected.

The manufacturer accepts no liability for any damage due to improper use of the luminaire.

Attention! Before working on the luminaire disconnect it from the mains. Also for cleaning, maintenance and lamp change.

Luminaires are only allowed to be used for the specified purpose. Interior lights may not be used in outside area. Luminaires may not be covered. They may not be connected to power supply still they are packaged. Lights with electronic control gears (ECG) have to be operated with original ECGs.

The lamp change must be done by a competent professional.

Use only lamps with same type of construction, performance and voltage.

In case of damages, in particular of cable and socket, the luminaire have to be shut off immediately. In case of damage on the mains cable it has to be changed by the Lichtlauf GmbH.

For malfunction call authorized personnel for troubleshooting. Never repair it by yourself.

Through improper repair work may arise risk for the user.

Elements of plug and connection shall be free from traction and torque.

care instructions

Disconnect the device from the power supply grid before cleaning.


The care of the lamp is limited to the surfaces. Make sure no liquid reach the connection area or electrical components.

Important:
Please don't use spiritus or alcohol containing products.
As well as no abrasives or abrasive containing detergents.

Use a damp cloth to clean the lamp.

For heavy soiling we recommend a plastic cleaner.

replacement of illuminants



1. Hold the lamp shade and open the three screw-nuts at the cover

2. Pull down the lamp shade carefully.

3. Replace the defective illuminant with a new one according to the information on the type plate.

4. Reattach the lamp shade securely with the screw-nuts.

Lichtlauf GmbH

Sonnentaustraße 12
80995 München

T +49(0)89.30905274-0
F +49(0)89.30905274-9

info@lichtlauf.de
www.lichtlauf.de